VIVE by **LUTRON**

── Line-voltage wiring

〰 Clear Connect RF Communication

DZ = Daylight Zones

| Symbol	Model Number	Description	Qty
	RMKS-DAL4-SZ	PowPak Single Zone Module with DALI	1
	LRF3-OCR2B-P-WH	Radio Powr Savr Wireless Ceiling Occupancy Sensor	1
	LRF3-DCRB-P-WH	Radio Powr Savr Wireless Daylight Sensor	1
	PK2-3BRL-TAW-L01	Pico Wireless Control On/Off and Raise/Lower	1
	LPFP-S1-TAW	Pico Wireless Faceplate (Single)	1

Control Strategies

Manual On / Auto Off	Max: 100% / Max: 85%
Occupancy/Vacancy	**High-end Trim/Tuning**
Full On / Dim	Full On / Dim
Daylight Harvesting	**Personal Dimming**

Lighting Energy Savings*

60%

* Go to lutron.com/references for more information.

Lighting Functionality

Occupant Enters:
Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually.

When Occupied:
Automatic: Overhead lights dim/brighten based on daylight availability.

Manual: Occupant uses wall dimmer to set desired light levels for all lights.

Occupant Exits:
All lights automatically shut off 15 minutes (by default) after all occupants exit.

> Add a Vive wireless hub to enable simple setup and rezoning, system monitoring, timeclock functionality, and advanced integration.

Visible System Components

Pico wireless control

Radio Powr Savr wireless ceiling-mount occupancy sensor and daylight sensor

Type of Solution

Dimming: Increased control, ambiance, and energy savings