VIVE by **LUTRON**

— Line-voltage wiring

〰 Clear Connect RF Communication

Symbol	Model Number	Description	Qty
	RMKS-DAL32-SZ	PowPak Single Zone Module with DALI	1
	LRF3-OKLB-P-WH	Radio Powr Savr Wireless Corner Occupancy Sensor	1
	PK2-3BRL-TAW-L01	Pico Wireless Control On/Off and Raise/Lower	1
	LPFP-S1-TAW	Pico Wireless Faceplate (Single)	1

Control Strategies

Manual On | Auto Off

Occupancy/Vacancy

Lighting Energy Savings*

40%

* Go to lutron.com/references for more information.

Lighting Functionality

Occupant Enters:
Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually.

When Occupied:
Manual: Occupant uses wall switch to turn all lights off.

Occupant Exits:
All lights automatically shut off 15 minutes (by default) after all occupants exit.

> Add a Vive wireless hub to enable simple setup and rezoning, system monitoring, timeclock functionality, and advanced integration.

Visible System Components

Pico wireless switch

Radio Powr Savr wireless corner-mount occupancy sensor

Type of Solution

Dimming: Increased control, ambiance, and energy savings.