

## Application Note #684


Revision A March 2018

# **Using Vive for Exterior Daylight Control**

Using Vive for exterior daylight control is possible when applying a WLCU301-CPN6814 and Daylight Control Package (GRX-CESO-xxx PKG). In this use case, the Daylight Control Package allows Lutron lighting control systems (such as Vive) to respond to ambient light levels in an outdoor application. The WLCU301-CPN6814 takes the wired sensor input from the Daylight Control Package and transmits Lutron Clear Connect commands back to the Vive system, similar to a Radio Powr Savr daylight sensor – see Wiring Diagram and Connections Table for details.

Note that unlike the Radio Powr Savr daylight sensor (LRF2-DCRB-WH), the Daylight Control Package features only adjustable on and off, and not continuous dimming.

### Wiring Diagram



### **Connections Table**

WLCU301-CPN6814	LC8 Controller	CES/O-12/24-0-10 Sensor
	Pin 1	Yellow
	Pin 4	Black
	Pin 5	Red
24 V	Pin 7	
Occupancy	Pin 8	

### **Additional Notes**

- 1. See the **Daylight Control Package** Specification Submittal (P/N 369746) for programming details for setting thresholds on an LC8 controller on www.lutron.com.
- 2. While the WLCU301-CPN6814 is programmed as an occupancy sensor in a Vive system, it should be the only occupancy sensor in the area.
- 3. Do NOT combine two controls with a time clock in the same area. See the **Design Recommendations When Using** Multiple Control Strategies App Note #629 (048629) at www.lutron.com for more information.
- 4. Light level is established through the WLCU301-CPN6814 occupancy sensor settings.
- 5. When Interfacing to a Lutron system, the N.C. contact will turn the lights ON (contact closure CLOSE) when the daylight levels are low and the lights turn OFF (contact closure OPEN) when the daylight levels are high.

Lutron, Clear Connect, and Vive are trademarks of Lutron Electronics Co., Inc., registered in the U.S. and other countries. Radio Powr Savr is a trademark of Lutron Electronics Co., Inc.

#### **Lutron Contact Numbers**

WORLD HEADQUARTERS USA Lutron Electronics Co., Inc. 7200 Suter Road Coopersburg, PA 18036-1299 TEL: +1.610.282.3800 FAX: +1.610.282.1243

support@lutron.com

www.lutron.com/support

North & South America Customer Assistance USA, Canada, Caribbean: 1.844.LUTRON1 (1.844.588.7661) Mexico: +1.888.235.2910 Central/South America: +1.610.282.6701

### EUROPEAN HEADQUARTERS

United Kingdom Lutron EA Limited 125 Finsbury Pavement 4th floor, London EC2A 1NQ United Kingdom TEL: +44.(0)20.7702.0657 FAX: +44.(0)20.7480.6899 FREEPHONE (UK): 0800.282.107 Technical Support: +44.(0)20.7680.4481

lutronlondon@lutron.com

#### ASIAN HEADQUARTERS Singapore Lutron GL Ltd. 390 Havelock Road #07-04 King's Centre Singapore 169662 TEL: +65.6220.4666 FAX: +65.6220.4333 Technical Support: 800.120.4491

lutronsea@lutron.com

#### **Asia Technical Hotlines**

Northern China: 10.800.712.1536 Southern China: 10.800.120.1536 Hong Kong: 800.901.849 Indonesia: 001.803.011.3994 Japan: +81.3.5575.8411 Macau: 0800.401 Taiwan: 00.801.137.737 Thailand: 001.800.120.665853 Other Countries: +65.6220.4666