


Catalog Volume 3


Connection Diagrams
for Quantum®

Processors



For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Processors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Processors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Processors



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



† Interface provides additional capacity and/or may be different voltage than control unit.


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



[†] Interface provides additional capacity and/or may be different voltage than control unit.


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



* Forward phase only; reverse phase will require an interface.


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



* DALI broadcast only

For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



* DALI broadcast only

For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



* DALI broadcast only


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed



For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




* Visit www.lutron.com/LEDtool for a complete list of LEDs compatible with this module.

** Forward phase only; reverse phase will require an interface.


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Dimmed



* Reverse phase only; forward phase will require an interface
** Visit www.lutron.com/LEDtool for a complete list of LEDs compatible with this module.


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Dimmed



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Switched



† Interface provides additional capacity and/or may be different voltage than control unit.

For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Switched



† Interface provides additional capacity and/or may be different voltage than control unit.

For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Switched



† Interface provides additional capacity and/or may be different voltage than control unit.


For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Switched




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Control options




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Timeclock scheduling




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Sensors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Sensors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Sensors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Sensors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Sensors



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Sensors




For illustration purposes only. Consult model number pages for specific voltage and capacity information.



Wired daylight sensor (continued)




Sensors



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Integration



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Window treatments

Software and programming



For illustration purposes only. Consult model number pages for specific voltage and capacity information.


Software and programming



¹ Apple and iPad are trademarks of Apple, Inc., registered in the U.S. and other countries

For illustration purposes only. Consult model number pages for specific voltage and capacity information.

Software and programming



* DALI emergency ballasts must be connected to Quantum system via an Energi Savr Node™ with DALI module

For illustration purposes only. Consult model number pages for specific voltage and capacity information.