


Installation Instructions


Please read before installing

International see Touch® Button/Faceplate Kits


Button/Faceplate Kits without Framed Insert



Button/Faceplate Kits with Framed Insert



Button Kits



Important Notes

Mounting: Ensure all controls are correctly wired and mounted before installing button kits or faceplates. Ensure controls are free from debris (e.g. plaster, spackling compound) before installing button kits or faceplates.

CAUTION: Handle Button Kits with care. The Button Kits contain sharp edges which could cause injury.

Buttons / Faceplates: Do not paint controls, faceplates, or buttons.

Cleaning: To clean, wipe with a clean damp cloth. Do not use any chemical cleaning solutions.

Replacing Button Kit

1 Remove existing button kit and faceplate.
Remove the existing button kit and faceplate from keypad (if applicable) by gently prying from the top.

Remove the button kit from the back of the faceplate by prying each side of the button kit from under each of the hooks.

2 Install new button kit into faceplate.
Holding the new button kit and faceplate with the front sides facing down, align the button kit with the opening in the faceplate. Slide one tab of the button kit under the hook on one side of the faceplate. Repeat for the other side (slightly bow the button kit to slide the tab under the hook). See *Button Kit Installation at right*.

3 Install assembled button/faceplate kit.
Make sure that the button kit is flush to the faceplate and secure. Install the assembled button/faceplate kit by firmly snapping onto the installed faceplate adapter. Press all four sides to be sure it is securely installed.

If the button/faceplate kit includes a frame (-I models), install the frame by snapping it onto the installed faceplate adapter. Press all four corners to be sure it is securely installed.

4 Check button/faceplate kit alignment.
If the button kit appears submerged, remove the faceplate. Loosen the keypad mounting screws and repeat steps 3 and 4 to reinstall the faceplate.

Button / Faceplate Kit Installation


1 Remove existing button kit and faceplate.
Remove the existing button kit, faceplate and faceplate adapter (if different color) from keypad by gently prying from the top.

2 Install faceplate adapter.
If the base keypad is already installed:
Loosen the keypad mounting screws. Install the faceplate adapter onto the keypad using the provided screws. Tighten the keypad mounting screws until the faceplate adapter is flush against the wall (do not over-tighten).


If the keypad is not already installed:
Install the faceplate adapter onto the keypad using the provided screws. Install the keypad using the keypad mounting screws (provided with the keypad). Tighten the keypad mounting screws until the faceplate adapter is flush against the wall (do not over-tighten).

3 Complete Steps 3 and 4 above.

Mounting Diagram



Button Kit Installation



Technical Assistance

If you have questions concerning the installation or operation of this product, call **Lutron's Headquarters**. Please provide exact model number when calling.

Worldwide Headquarters USA

Lutron Electronics Co., Inc
TEL: +1.610.282.3800
FAX: +1.610.282.1243
Technical Support: 1.800.523.9466
www.lutron.com

European Headquarters United Kingdom

Lutron EA Ltd.
TEL: +44.(0)20.7702.0657
FAX: +44.(0)20.7480.6899
Technical Support: +44.(0)20.7680.4481
Freephone: 0800.282.107
www.lutron.com/europe

Asian Headquarters Singapore

Lutron GL Ltd.
TEL: +65.6220.4666
FAX: +65.6220.4333
Technical Support: See Website for Toll-Free Numbers
www.lutron.com/asia

Limited Warranty

(Valid in the US, Canada, Mexico, and the Caribbean)
For warranty information, see the Limited Warranty that shipped with the product.

Limited Warranty

(Valid in European Union and Asia)

What This Warranty Covers

Lutron warrants each new Unit to be free from defects in materials or workmanship under conditions of normal use and specified ambient temperature when installed and operated in accordance with Lutron product specifications and applicable EU and local safety regulations.

What This Warranty Does Not Cover

This warranty does not cover:

- 1) Damage or improper operation determined by Lutron to be due to abuse, misuse, or accident, such as: (a) Use of incorrect line voltages; (b) Use of incorrect fuses or breakers; (c) Failure to follow operating instructions provided by Lutron; (d) Failure to maintain and operate equipment in accordance with applicable EU and local safety regulations; (e) Failure to maintain equipment under specified ambient temperature; (f) Unauthorized or improper repairs or adjustments; (g) Vandalism; and (h) Fire, flood, "Acts of God", and other problems beyond the control of Lutron.
- 2) Labor costs to remove and reinstall electronic fixture packs and/or ballasts.
- 3) Components and equipment external to the Lutron Unit, such as: (a) Lamps; (b) Ballasts, sockets, and fixtures; (c) Wiring between ballasts and lamps; (d) Building wiring; (e) Other manufacturers' equipment, such as: 1. Time clocks; 2. Audio-visual equipment; 3. Motion detectors; 4. Photosensors; 5. Driveway sensors; 6. Pressure pads; 7. Shades; and 8. Spas.
- 4) The cost of repairing or replacing property other than the warranted Unit.

What Lutron Will Do

To the extent permitted by law, Lutron will, at its option, repair or replace any Unit that is defective in materials or manufacture which, in Lutron's opinion, has been properly installed, wired, insulated, used, and maintained. Lutron shall not be required to remove, install, or re-install any defective Unit. Credit will be granted against the purchase price for replacement parts according to the following schedule:

For the first 2 years from the date of installation	100%
For years 3, 4, and 5 from the date of installation	50%
For years 6, 7, and 8 from the date of installation	25%

How To Get Service

Promptly notify Lutron if you believe the Unit is defective. Send the defective Unit, postage prepaid, with a brief written description of the problem to:
Lutron EA Ltd.
Lutron House
6 Sovereign Close
Wapping, London E1W 3JF England

Domestic and International patent(s) may be pending.
Lutron is a registered trademark in the United Kingdom. Lutron, HomeWorks, and seeTouch are registered trademarks in the Community Trademark System.
©2008 Lutron Electronics Co., Inc.