

Symbol	Model Number	Description	Qty
	RMJS-5R-DV-B	PowPak switching module	3
	LRF2-VKLB-P-WH	Radio Powr Savr wireless corner-mount vacancy sensor	1
	PJ2-2B-GWH-L01	Pico wireless 2-button control	3
	PICO-WBX-ADAPT	Pico wallbox adapter	3

Control Functionality

Occupant Enters:

Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually.

When Occupied:

Manual: Occupant uses wall switches to turn on and turn off general, white-board lighting, and perimeter daylight zone.

Occupant Exits:

All lights automatically turn off 15 minutes after all occupants exit.

Add a Vive wireless hub to enable simple setup and re-zoning, system monitoring, timeclock functionality, and advanced integration.