
Conference Room | Dimming Marshalling Box






Symbol	Model Number	Description	Qty
	RMKS-DAL32-SZ	PowPak Single Zone Module with DALI	1
	LRF3-OKLB-P-WH	Radio Powr Savr Wireless Corner Occupancy Sensor	1
:::	LRF3-DCRB-P-WH	Radio Powr Savr Wireless Daylight Sensor	1
	PK2-3BRL-TAW-L01	Pico Wireless Control On/Off and Raise/Lower	1
	LPFP-S2-TAW	Pico Wireless Faceplate (Dual)	1


Control Strategies







Daylight Harvesting



High-end Trim/Tuning



Personal Dimming

Lighting Energy Savings*



* Go to lutron.com/references for more information.



Lighting Functionality

Occupant Enters:

Lights do not automatically turn on when an occupant enters the space; lights must be turned on manually.

When Occupied:

Automatic: Overhead lights dim/brighten based on daylight availability.

Manual: Occupant uses wall dimmer to set desired light levels for all lights.

Occupant Exits:

All lights automatically shut off 15 minutes (by default) after all occupants exit.

Add a Vive wireless hub to enable simple setup and rezoning, system monitoring, timeclock functionality, and advanced integration.

Visible System Components



Pico wireless control



Radio Powr Savr wireless corner-mount vacancy sensor and daylight sensor

Type of Solution

Dimming: Increased control, ambiance, and energy savings

